



# Disassembling IBM ThinkPad T42 Rear Cover

Written By: Gerald Watanabe



## INTRODUCTION

The disassembly of the rear cover is simple but requires the removal of a lot of screws.

---



### TOOLS:


- [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — Rear Cover



- Unscrew the following screws on the underside of the T42.
- Note: for ease of reassembly, keep track of which screws go where.

## Step 2



- Unscrew the 4 screws on either side of the rear end of the laptop.

To reassemble your device, follow these instructions in reverse order.